

Red Sea REEFER™

425 G3+


Aquarium & Cabinet Assembly Manual




Resource & Support Center:
www.redseafish.com/support/



Aquarium Water Management System





Cabinet



		350 G3	425 G3
L1			
L2		4	4
N		57	57
M		52	56
M2		4	4
P		56	60
Q		56	60
S		2	2
W		2	2
V1	ST4x16	24	24
V2	ST3.5x14	4	4
V3	ST5x35	14	14
V4	ST5x60	2	2
W1		14	14
Y32-48		2	2
ZP			
ZW			
ZB			
		16	16

	Part Description	425 G3+
A1	Cabinet Bottom Sump	6617G2
A2	Cabinet Bottom Chiller	6618G2
B1	Cabinet Rear Middle	6628A-B
B2	Cabinet Rear Top	6629G2
B3	Cabinet Rear Bottom	6619A-B
B4	Cabinet Rear bottom support	6620
B5	Cabinet Side Top support Left	6615G2-L
B6	Cabinet Side Top support Right	6615G2-R
C	Cabinet Top	6616G3 (Located under the glass tank)
D	Cabinet Door	5275B/W
E	Cabinet Front Upper	6630
F	Cabinet Side Left	6624G3-B /WB
G	Cabinet Side Right	6625G3-B /WB
H1	Cabinet Sockel Black	6627G2-B
H2	Cabinet Sockel White	6627G2-WB
J	Cabinet Base Support	6626G2
K	Cabinet Internal Wall	6623G2


Return Pump Connectors

Hose-barbs for tube Internal Diameter		Quantity Included	Spare Part Kits		
			R45347 Union 25mm (¾")	R45348 Union 32mm (1")	R45350
	17/25mm (5/8" / 1")	2	1		
	25/32mm (1" / 1¼")	1		1	
Female threaded					
	¾" GAS	2	1		
	1" GAS	1		1	
Rigid PVC Pipe adapters					
	25mm (¾")	2	1		
	32mm (1")	1		1	
Screw Nuts					
	Screw Nut 25mm	2	1		
	Screw Nut 32mm	1		1	
Y-Split Connector					
	25 -32 Y Split Connector	1			1

1

Nx8

Mx6



2


B2

B1

B3

Px6

Qx6




3

Zx3

Mx5

Nx5




4

B4 (x3)

V3x6

Wx6



5

V4

Y32

K

V4 x2


Y32x2

350 G2+ 4

425 G2+ 6

M

Zx2




6

Mx2

Nx6

Zx5




7

J

K

Px5

Qx5




8

H

K

Px2

Qx2




9

E

V2x4

Wx2



10

M2

C


M2













M2








M2x4









Mx10

Nx14











37




X1

X2





38














V1x8

L2x4


39




Press and click on




MAINTENANCE




REGULAR MAINTENANCE




SECONDARY MAINTENANCE



VALVE REPAIR KIT





Europe

Red Sea Europe
655 Rue des Frères Lumière
27130 Verneuil d'Avre et d'Iton,
France
support.fr@redseafish.com

UK & Ireland

Red Sea Aquatics (UK) Ltd
PO Box 1237
Cheddar, BS279AG
support.uk@redseafish.com

North America

Red Sea U.S.A & Canada
4687 World Houston
Parkway #200
Houston, TX 77032, U.S.A
support.usa@redseafish.com

Germany & Austria

Red Sea Deutschland
Büro Deutschland
Prinzenallee 7 (Prinzenpark)
40549 Düsseldorf
support.de@redseafish.com

China

Red Sea Aquatics (GZ) Ltd.
Block 2-4, No.168, West Yingbin
Road, Xinhua Industrial Park,
Huadu District, Guangzhou City,
China, Postal code 510812.
Tel: +86-020-6625 3828
info.china@redseafish.com

 **Red Sea**
www.redseafish.com